

High Voltage Isolated Oscilloscope Probes

Why it is critical to properly and safely probe the VIC circuitry to prevent damaging of test equipment and to guarantee measurement accuracy.

- [DIY HV Isolated Probe](#)

DIY HV Isolated Probe

The following is a DIY probe you can make to isolate your scope from the high voltages of the VIC

277228430_391734796152825_4268011423781223452_n.png

Image not found or type unknown