

Impedance Intro

Introduction to Electrochemical Impedance

Electrochemical Impedance Spectroscopy (EIS) is a powerful technique for characterizing the electrical behavior of electrochemical systems like water fuel cells. Understanding impedance helps us model and predict how the WFC behaves across different frequencies.

What is Impedance?

Impedance (Z) is the AC equivalent of resistance. While resistance applies only to DC circuits, impedance describes how a circuit element opposes current flow at any frequency, including the phase relationship between voltage and current.

Impedance Definition:

$$Z = V(t) / I(t) = |Z| \times e^{j\theta} = Z' + jZ''$$

Where:

- $|Z|$ = impedance magnitude (Ohms)
- θ = phase angle between voltage and current
- Z' = real part (resistance-like)
- Z'' = imaginary part (reactance-like)
- $j = \sqrt{-1}$ (imaginary unit)

Impedance of Basic Elements

Element	Impedance	Phase	Frequency Dependence
---------	-----------	-------	----------------------

Resistor (R)	$Z = R$	0°	None
Capacitor (C)	$Z = 1/(j\omega C)$	-90°	$ Z $ decreases with f
Inductor (L)	$Z = j\omega L$	$+90^\circ$	$ Z $ increases with f

Why Use Impedance for WFC Analysis?

Impedance spectroscopy reveals information that simple DC measurements cannot:

1. **Separating processes:** Different phenomena occur at different frequencies
2. **Non-destructive:** Small AC signals don't significantly perturb the system
3. **Complete characterization:** Maps all electrical behavior across frequency
4. **Model fitting:** Allows extraction of equivalent circuit parameters

Electrochemical Impedance Spectroscopy (EIS)

EIS measures impedance across a range of frequencies to create a complete picture:


Typical EIS Procedure:

1. Apply small AC voltage (5-50 mV) superimposed on DC bias
2. Sweep frequency from high to low (e.g., 1 MHz to 0.01 Hz)
3. Measure current response at each frequency
4. Calculate impedance $Z = V/I$ at each frequency
5. Plot results as Nyquist or Bode diagrams

Nyquist Plot

The Nyquist plot shows the imaginary part ($-Z''$) vs. the real part (Z') of impedance:

$-Z''$ (Ohms)
↑



Reading a Nyquist Plot:

- **High frequency intercept:** Solution resistance (R_s)
- **Semicircle diameter:** Charge transfer resistance (R_{ct})
- **Semicircle peak frequency:** Related to $R_{ct} \times C_{dl}$
- **45° line at low frequency:** Warburg diffusion impedance

Bode Plot

The Bode plot shows magnitude and phase vs. frequency on logarithmic scales:

Bode Magnitude Plot:

$|Z|$ (log scale) vs. frequency (log scale)

- Flat regions indicate resistive behavior
- Slope of -1 indicates capacitive behavior
- Slope of +1 indicates inductive behavior

Bode Phase Plot:

Phase angle θ vs. frequency (log scale)

- $\theta = 0^\circ$ indicates resistive
- $\theta = -90^\circ$ indicates capacitive
- $\theta = +90^\circ$ indicates inductive

Frequency Ranges and Processes

Different electrochemical processes dominate at different frequencies:

Frequency	Process	Circuit Element
> 100 kHz	Bulk solution, cables	R_s , parasitic L
1 kHz - 100 kHz	Double layer charging	C_{dl}
1 Hz - 1 kHz	Charge transfer kinetics	R_{ct}
< 1 Hz	Mass transport (diffusion)	Z_w (Warburg)

Why This Matters for VIC

Understanding EIS helps VIC design in several ways:

- **Accurate modeling:** Know the true WFC impedance at your operating frequency
- **Frequency selection:** Choose operating frequencies that optimize energy transfer
- **Tuning:** Understand why resonance may shift during operation
- **Diagnostics:** Identify problems from impedance changes

Practical EIS for WFC Characterization

Equipment Needed:

- Potentiostat with EIS capability (or dedicated EIS analyzer)

- Three-electrode setup (working, counter, reference)
- Shielded cables to minimize noise
- Faraday cage for low-frequency measurements

Alternative for Hobbyists:

An audio frequency generator + oscilloscope can characterize WFC in the 20 Hz - 20 kHz range relevant to most VIC circuits.

Key Takeaway: Electrochemical impedance reveals that a WFC is far more complex than a simple capacitor. Its impedance varies with frequency, voltage, temperature, and time. The equivalent circuit models in the following pages help capture this complexity for VIC design.

Next: The Randles Equivalent Circuit →

Revision #1

Created 2026-01-01 20:38:05 UTC by Chris Bake

Updated 2026-01-01 20:38:20 UTC by Chris Bake