

Pulsing Transformer

The **pulsing transformer** (A/G) steps up the voltage amplitude or voltage potential during pulsing operations.

The primary coil is electrically isolated (no electrical connection between primary and secondary coil) to form **Voltage Intensifier Circuit** (AA) Figure (1-1).




FIGURE 1-1: VOLTAGE INTENSIFIER CIRCUIT (AA)

Voltage amplitude or voltage potential is increased when **secondary coil** (A) is wrapped with more turns of wire.

Isolated electrical ground (J) prevents electron flow from input circuit ground.

Revision #2

Created 19 December 2023 18:30:22 by Chris Bake

Updated 20 December 2023 04:43:51 by Chris Bake